

ASSEMBLY - MODEL 336-2

Loop tether through

Connecting Rod
Rotate clockwise
for tightening

Tighten tether
around Connecting
Rod handle

Hold Down Cap
Rotate slightly to
lock groove onto
sheath

Anchor Pin
Qty 4 typ.

Collapsible, Retro-Reflective
Sheath

Anchor Pin (1) 12"
Once marker is
assembled,
snug-up tether
and install tether
pin

Fill Plug

Moulded Base

NOTES:

- INSTALL SQUARE AND LEVEL
- USE SUPPLIED ANCHOR PINS OR FILL BASE WITH WATER, SAND ETC.

REVISIONS: 11/14/02- /sm
ADD TETHER AND TETHER PIN

REGINALD BENNETT INTERNATIONAL Inc. RBI "OUR PRODUCTS SAVE LIVES"	DWG NAME: MODEL 336-2		VIEW: Iso/Explosion		
	DATE: (MM/DD/YY) 11/27/95	DRAWN BY: Steve McCarley	MATERIAL: As Shown	ISSUED TO:	JOB No.: RBI001
	SCALE: NONE	UNITS: OK'D BY: mm	FILE NAME: RB C 336B1	DWG No.: M336B-A1	